

MODEL 23A00-2 FLUSH REMOTE TEMPERATURE SENSOR
Cat. No. 23A00-2
Installation Instructions and User's Guide



DI-021-EM232-00A
(23100-2)

INSTALLATION

ENGLISH

WARNINGS AND CAUTIONS

- Read and understand all instructions. Follow all warnings and instructions marked on the product.
- Do not use this product near water - e.g., near a tub, wash basin, kitchen sink or laundry tub, in a wet basement, or near a swimming pool.
- Never push objects of any kind into this product through openings, as they may touch dangerous voltages.
- SAVE THESE INSTRUCTIONS.

WARNINGS AND CAUTIONS

- Never install communications wiring or components during a lightning storm.
- Never install communications components in wet locations unless the components are designed specifically for use in wet locations.
- Never touch uninsulated wires or terminals unless the wiring has been disconnected at the network interface.
- Use caution when installing or modifying communications wiring or components.

DESCRIPTION


The Model 23A00-2 is a flush mount temperature sensor that can be installed on an Omnistat2 thermostat to monitor the temperature of a remote location, can be combined with the onboard temperature sensor for the average temperature of two locations, or can be used to monitor the outdoor temperature for dual fuel heat pump installations.

When used indoors, the remote sensor allows a customer to monitor the temperature of an area without having a visible thermostat. The thermostat, or group of thermostats, could be in a different location offering the customer complete control of temperatures.


INSTALLATION

1. Install Omnistat2 base in selected thermostat location and connect to heating/cooling equipment per manufacturer's instructions.
2. Connect thermostat to base and confirm that everything operates correctly. Disconnect the thermostat from the base.
3. In selecting a place to mount the Remote Temperature Sensor, be sure to avoid an area where studs, plumbing, or electrical wiring may be located behind the wallboard. Hold the base of the plastic case against the wall. Trace around the perimeter of the plastic case with a pencil. Carefully cut along the pencil line. **DO NOT OVERSIZE THIS CUT-OUT!**
4. Run a twisted pair, shielded cable from the Omnistat to the Remote Temperature Sensor location. For distances up to 100 feet, typical twisted pair, PVC-insulated, shielded cable may be used. For distances from 100-150 feet, twisted pair with polypropylene insulated conductors, shielded must be used. For distances from 150-250 feet, twisted pair with foam-polyethylene insulated conductors, shielded must be used. Wire runs must not exceed 250 feet.
5. Connect the data wires of the shielded cable to the green data wires of the temperature sensor using the supplied wire splices. Wrap the shield around the jacket of the cable and tape.
6. Insert the Remote Temperature Sensor base into the cutout in the wall.
7. At the Omnistat2 location, make the connections to the Green and Black terminals under the section marked "Remote Temp Sensor" on the right terminal strip. Note that the shield and one of the wires from the remote temperature sensor are tied together and get connected to the Black terminal – See Figure 2.

**FIGURE 1
INSTALLING THE FLUSH SENSOR**



**FIGURE 2
OVERALL INSTALLATION DIAGRAM**



CONFIGURATION

Reconnect the Omnistat2 to the base and configure the remote temperature sensor according to the application.

The Temperature Sensor Installation Settings are used to configure the internal temperature sensor and optional remote temperature sensor that is connected to the thermostat. Any temperature sensors that are set as the same type (i.e. indoor or outdoor) will display the average temperature reading among the sensors. An asterisk (*) next to a setup item indicates the default setting.

- Internal Sensor: This will enable or disable the onboard temperature sensor for indoor use only. *Enabled
- External Sensor 1: This will enable the external temperature sensor for indoor or outdoor use. All indoor and outdoor temperatures are averaged between all sensors of the same type. *Disabled

OPERATION

On the Omnistat2 Home Page, confirm that the thermostat is displaying the proper temperature. If the remote temperature sensor is configured as "outdoor", confirm that the proper outdoor temperature is displayed in the Message Bar on the Omnistat2.

FOR CANADA ONLY

For warranty information and/or product returns, residents of Canada should contact Leviton in writing at **Leviton Manufacturing of Canada Ltd to the attention of the Quality Assurance Department, 165 Hymus Blvd, Pointe-Claire (Quebec), Canada H9R 1E9** or by telephone at **1 800 405-5320**.

LEVITON LIMITED WARRANTY

Leviton warrants to the original consumer purchaser and not for the benefit of anyone else that products manufactured by Leviton under the Leviton brand name ("Product") will be free from defects in material and workmanship for the time periods indicated below, whichever is shorter: • **OmniPro II and Lumina Pro**: three (3) years from installation or 42 months from manufacture date. • **OmniLT, Omni Ite, and Lumina**: two (2) years from installation or 30 months from manufacture date. • **Thermostats, Accessories**: two (2) years from installation or 30 months from manufacture date. • **Batteries**: Rechargeable batteries in products are warranted for ninety (90) days from date of purchase. **Note**: Primary (non-rechargeable) batteries shipped in products are not warranted. **Products with Windows® Operating Systems**: During the warranty period, Leviton will restore corrupted operating systems to factory default at no charge, provided that the product has been used as originally intended. Installation of non-Leviton software or modification of the operating system voids this warranty. Leviton's obligation under this Limited Warranty is limited to the repair or replacement, at Leviton's option, of Product that fails due to defect in material or workmanship. Leviton reserves the right to replace product under this Limited Warranty with new or remanufactured product. **Leviton will not be responsible for labor costs of removal or reinstallation of Product.** The repaired or replaced product is then warranted under the terms of this Limited Warranty for the remainder of the Limited Warranty time period or ninety (90) days, whichever is longer. This Limited Warranty does not cover PC-based software products. **Leviton is not responsible for conditions or applications beyond Leviton's control. Leviton is not responsible for issues related to improper installation, including failure to follow written Installation and operation instructions, normal wear and tear, catastrophe, fault or negligence of the user or other problems external to the Product.** To view complete warranty and instructions for returning product, please visit us at www.leviton.com.

Use herein of third party trademarks, service marks, trade names, brand names and/or product names are for informational purposes only, are/may be the trademarks of their respective owners; such use is not meant to imply affiliation, sponsorship, or endorsement.